

Model No.	Track Style & Ref. Notes	RP or RPE	RP or RPE Head & QK	Record Head & QK	Playback Head & QK	Erase Head & QK
SONY (Continued)						
TC850	4S			8604+96	8607+96	NONE
TC850	4CH			5604+96	5603+96	NONE
TC900	2M	RP	3202+21			NONE
TC905A	2M - 2	RP	3201			NONE
TC910	2M	RP	3202+21			NONE
111	2M	RP	3200			NONE
250	4S - 72, 73	RP	1207+102			1401+306
250A	4S	RP	1202+102			1401
252	4S	RP	1207+102			
252D	2S	RP	2007+102			
252D	4S	RP	1207+102			
262D	4S	RP	1200+102			1402+305
262SL	4S	RP	1200+102			1402+305
263	4S			1210+102	1200+102	1402+305
263D	4S			1210+102	1200+102	1402+306
263E	4S			1210+102	1200+102	1402+305
300	4S	RP	1200+119			1402+305
350	4S - 73			1210+102	1207+102	1401+305
464CS	4S	RP	1200+102			1402+305
464D	4S	RP	1200+102			1402+305
464SL	4S	RP	1200+102			1402+305
500	4S	RP	1200+102			1402+305
521	4S	RP	1200+102			1402+305
555A	2S - 81, 23	RP	2000+38			2202+18
555A	4S - 81, 23	RP	1200+38			1402+18
660	4S	RP	1207+102			
728-4	NONE					
748	NONE					
777S-2	2S			2010+102	2002+102	2202+305
777S-4	4S			1210+102	1202+102	1402+305
1000D	NONE					
1028	NONE					
1048	NONE					

SOUNDESIGN

A6011	8S				5800	NONE
494	8S				5800	NONE
4469	8S				5800	NONE
4488	8S	P			5800	NONE
4769	8S				5800	NONE
4962	8S	P			5800	NONE
4965	8S	P			5800	NONE
4983	8S				5800	NONE
6515	2M	RP	5132			NONE
7604	2M - 39	RP	5140A			NONE
7613	2M - 39	RP	5140A			NONE
7620	2M	RP	5140A			NONE
7622	2M		NONE			NONE
7623	2M - 39	RP	5140A			NONE
7628	2M		NONE			NONE
7718	2M - 34	RP	5140A			NONE
7825	2M	RP	5140A			NONE
7839	2M - 39	RP	5140A			NONE
7841	2M	RP	NONE			NONE
7843	2M	RP	5140A			NONE

SPARTA (See Professional Guide)

STANCIL HOFFMAN (See Professional Guide)

STAR-LITE

TT37	2M - 36	RP	3101+21			3600+19
TT42	2M - 36	RP	3101+21			3600+19

STARLIGHT METZNER (See METZNER)

STEREOSONIC

499S	8S				NONE	
971S	8S				5800	

STEREOTONE

130	2M - 1	RP	8403+35			8301+35
183,130	4S	RP	1201+38			
183,130	2M	RP	8403+38			

SUNDSTRAND (See Professional Guide)

SUPERSCOPE

C101	2M	RP	5140A			NONE
C103	2M	RP	NONE			NONE
CD301	2M - 39	RP	5230A			NONE
CD304	4S	RP	5230A			NSI
K304	2M	RP	5140A			NSI

SURROUNDING SOUND

T500	FT - 1			9107	9102	NSI
------	--------	--	--	------	------	-----

SYLVANIA

CT90BK	2M	RP	5140A			NONE
CT100	2M	RP	5140A			NONE
CT110W	2M	RP	NONE			NONE
CT150	4S - 39	RP	5230A			NONE
CT160W/1	4S		NONE			NONE
CT170W	4S - 39	RP	5230A			NONE
CTR140BK	2M	RP	NONE			NONE
CTR175W	4S	RP	5230A			NONE
ET203	8S - 39			5800		
ET204	8S - 39			5800		
ET206	8S - 39			5800		
ET2750	8S - 39			5800		
TC1	2M - NONE					
1-400-1	2M	RP	3250			3600+18
1-400-2	2M	RP	3250			3600+18
1-628-1	2M	RP	3250			3600+18
4901	2M	RP	3250			3600+18

SYMPHONIC (See also V-M)

CP20A	8S - 39				5800	
CR40	2M - NONE					
CR142	2M - 39	RP	5230A			NONE
TPS300	2M - 75	RP	5140A			NONE

Model No.	Track Style & Ref. Notes	RP or RPE	RP or RPE Head & QK	Record Head & QK	Playback Head & QK	Erase Head & QK
TANDBERG						
3B	2M - 58					
6	4S - 57, 25	RP		3201+21		NSI
11P	FT			1205+82	1200+82	8704+82
62	4S - 57, 25			NONE	NONE	NONE
62X	2S			1205+82	2000+82	8704+82
64	4S - 57, 25			1205+82	1200+82	8704+82
64X	4S			NONE	NONE	NONE
65	4S - 57, 25			1205+82	1200+82	8704+82
72	4S	RP		1202+82		8704+82
72B	4S	RP		1202+82		8704+82
74	4S - 57	RP		1201+82		8704+82
74B	4S - 57	RP		1201+82		8704+82
82	2M - 60	RP		8403+82		8301+82
84	2M - 60	RP		8403+82		8301+82
821	2M - 60	RP		8403+82		8301+82
822	2M - 60	RP		8403+82		8301+82
823	2M - 60	RP		8403+82		8301+82
824	2M - 60	RP		8403+82		8301+82
841	2M - 60	RP		8403+82		8301+82
842	2M - 60	RP		8403+82		8301+82
843	2M - 60	RP		8403+82		8301+82
921	FT - 63	RP		9111+82		8101+82
922	FT - 63	RP		9111+82		8101+82
923	FT - 63	RP		9111+82		8101+82
1041	2S					
2303P	4S			NSI	8210+82	NSI
				NONE	NONE	NONE

TAPEMASTER

PT121	2M	RPE	NONE			
PT125	2M	RPE	NONE			
TH21	2M	RPE	NONE			

TAPESONIC

TRS70A	2S			2003+38	9202+38	NSI
7DHT	2M	RP	8403+35			
70	2M	RPE	NONE			
70B	2M	RP	3101+20			3601+18
70C	2M			3205+21	3200+21	3601+19
70C	4S			1203	8600	1401+18
70D	2M			8404	8400	3601
70E-SHT	2S			2003-NSI	2000-NSI	2201-NSI

TEAC (See Professional Guide also)

A350	4S	RP	NONE			NONE
A7030	2S					
124	4S	RP	5230A	9203+85	9213+85	9226+66
160	4S	RP	5230A			5212
						NSI

TELECTRO (See also AIRLINE)

A	2M	RP	3101+20			NONE
GEN3627A	2M - 2	RP	3101			NONE
GEN3638A	2M - 2	RP	3101			3600+19
GEN3647A	2M - 2	RP	3101			3600+19
48	2M	RP	3201+20			NONE
113	2M	RP	3201+20			NONE
122	4S	RPE	6009+38			
132	4S	RPE	6009+38			
200	4S - 39	RP	1207			1401+19
201	2S - 39	RP	2002			2201+19
201/E50/60	4S	RP	1203+66			1401
213	2M	RP	3201+20			NONE
215	2M	RP	3201+20			NONE
223	4S	RPE	6009+38			
241	2M	RP	3200+20			3601+18
300	2M - 70	RP	1200+38			3601+18
333	2M - 70	RP	1200+38			3601+18
350	2M	RP	3200+20			3601+18
359	2M	RP	3200+20			3601+18
360	2M - 70	RP	1200+38			3601+18
400	4S	RP	1200+38			1401+18
441	2M - 70	RP	1200+38			3601+18
442	4S	RP	1200+38			NONE
461	4S			1200+38		1401+18
461	4S - Add A Sound			1200+38		
511	2M	RP	3201+20			NONE
556	2M	RP	3201+20			NONE
591	2M	RP	3200+20			3601+18
900-1	4S	RP	1200+38			1401+18
938	FT			9103+35	9111+35	8101+35
1960	2M	RP	3200+20			NONE
1965	2M	RP	3200+20			NONE
1970	2M	RP	3200+20			NONE
1975	4S	RP	1200+38			NONE
1980	4S				1200+38	
3627A	2M - 2		3101			NONE
3734	2M			3200+20		NONE
3739A	2M			3200+20		NONE
3739B	2M			3200+20		